

## **KWB MULTIFIRE**

Wood chip and wood pellet heating system

We provide

energy

for life!





# KWB MULTIFIRE

Wood chip and pellet heating system 20–120 kW

Robust all-rounder for economical heating

www.kwb.net

clean EFFICIENCY
Combustion technology

# Valuable Partnership

ore than 2,000 installers and more than 60,000 customers put their trust in us by deciding in favour of a KWB partnership. This "valuable asset" is also an integral component of our company philosophy and the basis of our business relationships. In addition, KWB focuses on appreciation, reliability and a large amount of responsibility vis-à-vis our environment and future generations. This I guarantee personally and this is also symbolised by KWB's trademark: the tree of life.



# Content

#### Introduction

- 2 Preface & Contents
- 3 The company KWB
- 4-5 KWB Multifire: Robust all-rounder for economical heating
- 6-7 KWB Crawler burner
- 8-9 Our advantages Your benefit
- 10 CleanEFFICIENCY
- 11-13 Comfort 3 control

#### Fuel storage and conveyor systems

- 14–15 Overview fuel storage and conveyor systems
- 16-19 Conveyor systems
- 20–28 KWB installation examples

#### Installation and connection

29-30 Installation and connecting dimensions

#### **Technical specifications**

- 31–32 Overview in table format
- 33-36 Required structural conditions
- 39 Guarantees and warranties









KWB stands for power and heat from biomass and is synonymous with innovative biomass heating systems. It developed, for example, the first wood chip heating system with a fully automatic heat exchanger cleaning. In 2006, the largest private research and development centre for biomass in Europe was established at the company's main location in Austria. What else speaks for a partnership?

# **97% of our customers** recommend KWB to others

According to recent customer surveys, 97% of all KWB customers recommend the company KWB and its products to others. Satisfied customers are the highest praise for a company – a priceless token of trust!

### **Noticeable benefits**

## through product development

When working on the further development of the KWB product line, our main focus is on the tangible and noticeable benefits for the partner and end customer with a high functional safety, while presupposing a high-quality, robust high-tech product.

#### Safety

### because of our award-winning service

Availability, flexibility, proximity to our customers are customer service requirements that must be met. KWB's own factory customer service exceeds these expectations and has received several related awards.

### Time savings

### $through\ effortless\ comfort$

Thanks to our close partnership with installers and design companies, a large amount of valuable experience contributes to the product development and guarantees the highest possible installation and operating comfort, which helps save what is most valuable to us: time.





# ROBUST ALL-ROUNDER

The large power range of 20 to 120 kW combined with highest fuel flexibility makes it possible to deploy the new KWB Multifire wood chip and pellet heating system in a larger single family home, in commercial facilities including smaller district heating networks.



#### Clean combustion

Stress-free combustion thanks to a variable rotary grate speed and air supply



# High efficiency combustion


Complete and almost emissionfree combustion through special geometries and materials

## CFD-optimised silicon-carbide combustion chamber

low emissions thanks to streamingoptimised exhaust gas routing and high combustion temperatures


#### CFD-optimised nozzle geometry and arrangement

full wood gas combustion thanks to optimal turbulation and a long retention period



One-chamber cellular wheel sluice

robust cast housing with hardened, replaceable cutting edges, a deep filling chamber and large sealing surfaces





#### **Return flow boost**

optimised hydraulics and aligned with the system



2-button control with dial and an easy to understand graphic display



into a convenient ash container with integrated fill level monitoring

## Cellular wheel sluice

Maximum operating safety and incident-free operation



KWB




## High efficiency turbulators

Optimal heat exchange with lowest exhaust gas temperatures and a consistently high efficiency coefficient

crawler burner with high-alloy and selfcleaning cast rotary grate elements


# KWB CRAWLER BURNER

The new KWB Crawler Burner\* is the centrepiece of the new KWB Multifire wood chip and pellet heating system. Thanks to its fuel flexibility and its automatic adjustment to changing fuel qualities, the KWB Crawler Burner\* is a true all-rounder, which is well-equipped to deal with wood chips and pellets as well as agricultural fuels.



B.







#### Power-saving high efficiency ignition

extremely short ignition times thanks to a ceramics ignition element and quick igniter recognition



## **Stress-free combustion**

Quiet fuel bed thanks to an even and slow rotary grate speed for lowest emissions





# Fuel recognition plus\*

Highest fuel utilisation despite changing fuel quality thanks to the combustion control's automatic adjustment (rotary grate speed and air supply)

# **OUR ADVANTAGES**

clean EFFICIENCY TECHNOLOGY



# Clean and efficient through a twice-controlled combustion

While the broadband lambda probe in the burnout control ensures minimum emissions, a full fuel utilisation is ensured by the highly sensitive temperature sensor in the burnout control.



## High fuel flexibility

The KWB Crawler Burner makes it possible to use different fuels such as wood chips, pellets as well as agricultural fuels of varying quality.



# Clean and efficient thanks to a highly efficient combustion

The combustion room design, which was optimised with a computer-aided simulation, is perfectly supported by the high-temperature silicon carbide lining and thus achieves excellent combustion conditions with lowest emissions.



# Efficient due to a high efficiency factor

The proven high efficiency turbulators from the KWB product family guarantee an optimal heat exchange through which they reach a consistently high efficiency coefficient both in partial load as well as nominal load.

# YOUR BENEFITS

#### KWB MULTIFIRE WOOD CHIP AND PELLET HEATING SYSTEM



#### **Space-saving**

The new KWB Multifire impresses thanks to the various space-saving installation options and can even be placed directly in wall corners or in rooms with very low ceilings.



# Easy planning and installation

It is very easy to transport the heating system into any type of heating room thanks to the delivery process and because it can be quickly disassembled into modules. The fuel feed can occur either from the left or the right and can be determined on site.



# Minimum power consumption

Intelligent drive motors (load-dependent power use) ensure extremely low power consumption. In addition, a large cellular wheel sluice ensures lowest power use and smooth fuel transportation. Additional power savings are achieved with the help of our time-tested hopper.



## Installationand service-friendly

The easy access to specific inspection points and the effortless replacement of individual modules makes the service personnel's work significantly easier. In addition, a start-up assistant leads the operator quickly and actively through the commissioning process.

# cleanEFFICIENCY

## COMBUSTION TECHNOLOGY

CLEANEFFICIENCY is a label that we give to KWB heating systems which are built to achieve lowest emission values, highest efficiency and use very little fuel and energy and were specifically optimised to provide a perfect interaction of construction and control elements.

clean EFFICIENCY sums up in one word the technology package developed by the KWB Innovation Centre that achieves higher efficiency, lower emissions and maximum comfort.

Thanks to KWB's many years of expertise, the KWB Multifire with cleanEFFICIENCY was further perfected in a comprehensive system, which makes it synonymous with modern high-tech biomass heating systems.

The differences between the KWB Easyfire and regular models are evident in clearly visible technical and geometrical measures as well as fine-tuning and subtle differences imperceptible at first glance.

√ Lowest emission values

✓ Maximum efficiency


clean EFFICIENCY is thus also a response to a looming climate change as a result of increasing environmental burdens. It is a future-oriented technology that offers a further decrease of pollutant emissions with consistently efficient heating performance with highest levels of efficiency and maximum comfort. The clean EFFICIENCY technology makes an enormous contribution in this respect.

As a visible result, the heating systems remain significantly below the limit values for emissions and are at the limit of what is technically measurable. This applies to both the partial load and nominal load.

✓ Fuel- and power-saving technology

✓ Perfectly aligned comprehensive system





# KWB COMFORT 3

THE COMFORTABLE CONTROL

# **EASY OPERATION**

## **KWB Comfort 3 Microprocessor control system**

**KWB Comfort 3** is a modular system that is used to operate and regulate KWB biomass heating systems.

All adjustments can be executed using the 2-button control unit together with a dial on the innovative, easy to understand graphic display. It is also easy to configure the parameters for boiler, heating circuit, DHWC and buffer tank by using the logically structured menu system. The control unit fully automatically and infinitely variable adjusts boiler output according to heat

demand from standby to full load. The control concept ensures optimum combustion conditions, lowest emissions and maximum economic efficiency.

In addition to regulating the burner, it also provides comprehensive heat management – from a single-family house to a district heating network. As a modular, expandable system, the KWB Comfort 3 makes it possible to control up to 32 heating circuits, 16 buffer tanks and 16 DHWCs.

It is also possible to link several digital or analogue remote-control devices.

## The control unit consists of the following components:



#### Master board

Contains all inputs/outputs for boiler control, incl. sensors and terminal strip for external connections. The master board also includes the activation for one DHWC and one buffer tank with two temperature sensors.



#### **Boiler control unit**

This module is used to operate and regulate the boiler and for heat management purposes.



#### Heating circuit expansion module

Controls a max. of 2 heating circuits, one DHWC and one buffer tank (with 2 sensors) per module. Operation and monitoring are carried out using the boiler control unit or optionally using digital remote control devices.



#### Analogue remote control unit

Easy operation for one heating circuit with room sensor, respectively, consisting of a dial for adjusting the desired room temperature by  $\pm 5\,^{\circ}$ C and a 4-position slide switch for selecting the heating program: automatic mode, lower mode, frost protection mode or day operation.



#### Digital remote control unit

Makes it possible to control one or more heating circuits with room sensor and to configure and monitor the heating circuit, DHWC and buffer tank management from the living room.



#### **KWB Comfort Solar**

The KWB Comfort Solar control system controls the heating system such that the free of charge solar energy is optimally routed into the buffer tank. In addition to functionality and design, the solar control system features an easy-to-use and self-explanatory user interface. A convenient commissioning wizard is available to the heating engineer.

## **KWB Comfort SMS**

You can query the current operating status and actively control the heating system using your mobile phone (e.g. holiday program, party operation).

In addition to switching the heating system on and off, the operator can query current operating modes or make adjustments to the heating circuits, DHWC, buffer tanks, etc. In addition, alarm messages are sent to the

mobile phone. The sender receives acknowledgement of commands that have been executed through a reply by text message (SMS). The generation of commands and queries is simplified trough the use of text message (SMS) templates that can be transmitted to the respective mobile phone by the KWB Comfort 3. KWB Comfort SMS is available in German, English, Italian, French, Spanish and Slovenian.

## **KWB Comfort Visio**

KWB Comfort Visio is an additional component of the KWB Comfort series for visualisation, remote monitoring and remote control of your KWB heating system via your PC.

The conceptualisation of the KWB Comfort Visio with respect to project design and commissioning is truly revolutionary: connect and switch on, that's all it needs – the KWB Comfort Visio automatically adjusts to the heating system. KWB Comfort Visio is available in English and German.

#### Monitoring and operation

The KWB Comfort Visio displays operating values of boiler, heating circuits, DHWCs and buffer tanks. The visualisa-

Serial or TCP/IP

Modem

Modem

Modem

Access to the visualisation PC via separate software.

Option 1: Visualization PC near the system


tion interface displays all configuration parameters of the heating system where they can be adjusted. In addition, the KWB Comfort Visio offers a comprehensive alarm management system, consisting of alarm statistics and log, as well as an extensive help system for the specific alarms.

#### **Archiving**

When using a computer on site, it is possible to use the comprehensive data recording and evaluation options of the KWB Comfort Visio.

#### Remote maintenance

The heating system can be accessed from any location via modem. It is thus possible to monitor the heating system and intervene if necessary. This makes it also possible for the KWB customer service to remotely maintain the customer's heating system.



Option 2: No PC near the system

## **KWB Comfort InterCom**

The KWB Comfort InterCom is an interface that facilitates the data exchange between the KWB Comfort control and external systems.

As, for example, higher level control or regulation systems or building automation systems. The data

exchange takes place by means of a serial connection, network connection or analogue modem connection. All boiler operating status parameters as well as individual alarms can be read out on the KWB Comfort control system. In addition, the external system can modify several parameters in the KWB Comfort control system. Option 2: No PC near the system

# **FUEL STORAGE & CONVE**

## OPTIMISED FOR ANY TYPE OF REQUIREMENT

Aside from developing modern wood chip and pellet heating systems, KWB possesses extensive expertise with respect to the optimal storage and conveyance of wood chips and pellets. Thanks to KWB's flexible and diverse conveyor module system, a solution can be found for almost every structural situation.



Heating system in adjoining building KWB Multifire with stirrer and conveying channel; direct storage room filling using tractor and front end loader



Heating system in the basement of a building KWB Multifire with stirrer and conveying channel; direct storage room filling from traile

# YOR SYSTEMS

#### Fuel consumption and storage room size for wood chips

Heating load of the building [kW]	Consumption per year* [m³/a]	Storage room size for annual requirement*
20	50	74.0
30	75	111.0
40	100	148.0
50	125	185.0
60	150	222.0
80	200	296.0
100	250	370.0
120	300	444.0

\* Using wood chips with 25 % water content and size P16B according to FN 14961-4

Annual utilisation factor: 2.5 m³ per kW heating load, Storage room size factor for annual requirement: 3.7 m³ per kW heating load



Heating system in seperate boiler house KWB Multifire twin boiler installation with common stirrer and two conveying channels; direct storage room filling from trailer




Heating system in the basement of a building KWB Multifire with stirrer and conveying channel; direct storage filling via screw auger from bunker

# **KWB STIRRER**

## RELIABLE, LONG SERVICE LIFE

The KWB conveyor system, which consists of a stirrer (stirrer diameter: 2.5 to 5.5 m) and conveyor screw on a massive hollow shaft supported by two bearings, is customized with respect to length and diameter based on the customer's structural conditions. Storage rooms may be square, rectangular or round and can be situated above the heating room, at the same level or below it.



## reliable and long service life


- Long service life and high wear resistance of the screw thanks to stainless steel spirals in the feed area and a maintenance-free, double-sealed heavy-duty gear unit in trough form.
- ✓ No buoying upwards of the conveyor screw in the channel due to an optimised channel shape.
- ✓ No overfilling of the conveyor screw channel due to progressively ascending spirals, an asymmetric opening and a reverse conveyor screw.

#### comfortable and customised

- Efficient emptying of the fuel storage room even with larger stirrer diameters due to the uniform contact force of the articulated-blade rotary stirrer over the entire diameter.
- Low power consumption
  through avoidance of mechanical resistance.
- Full utilisation of the storage room space
  is possible due to the various ascending screw options.
  The conveyor screw length is adjustable upon the customer's request.

#### **Broad fuel flexibility**


The conveyor system is suitable for wood chips of the categories A1, A2 and B1 up to a grain size of P16B, P45A in accordance with EN14961-4 as well as for the transport of wood pellets of the quality levels A1 and A2 in accordance with EN14961-2.




# STIRRER WITH CONVEYOR SCREW


Depending on requirements, the stirrer is available in two different versions: as a spring blade rotary stirrer (stirrer diameter between 2.5 and 4.0 m) and as an articulated blade rotary stirrer (stirrer diameter between 4.0 and 5.5 m).

#### **Outline**



#### Ground plan






As shown in the diagram, a recess must be provided when the conveyor system is lowered into the ground. The depth of the recess is 22 cm. When the stirrer is lowered into the ground, the channel must be additionally equipped with at least 2 cm of acoustic insulation. The channel must be acoustically decoupled from the ground.

- c1 It must be possible to dismantle the inclined floor or false floor up to 30 cm around the channel!
- Wall duct 60×60 cm: seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- Diameter of the stirrer cover plate: spring blade stirrer:
- Ø85 cm, articulated blade stirrer: Ø110 cm.
- Diameter of the stirrer: spring blade stirrer: Ø 2.5 m, 3.0 m, 3.5 m, 4.0 m (4.5 m only for pellets), articulated blade stirrer: Ø 4.0 m, 4.5 m, 5.0 m, 5.5 m


# STIRRER WITH ASCENDING SCREW

For situations where there are level differences between storage room and heating room, or for a horizontal installation of the stirrer, we offer two innovative ascending-screw models: an ascending screw with upward transfer and an ascending screw with downward transfer.

#### Ascending screw with upward transfer



#### Ascending screw with downward transfer




D7	Wall duct 60×60cm: seal after installation; the channel must be acoustically decoupled (at least 2cm acoustic insulation)
Εl	Swing range ascending screw
Fl	Free rotation
N2	Shaft depth: 0°-25°: ≥ 45 cm, 26° - 35°: ≥ 50 cm, 36° - 45°: ≥ 60 cm
0	Incline for wood chips: 5°–45°, Incline for pellets: 0°–40°
ΡI	Diameter of the stirrer cover plate: spring blade stirrer: Ø 85 cm, articulated blade stirrer: Ø 110 cm. Diameter of the stirrer: spring blade stirrer: Ø 2.5 m, 3.0 m, 3.5 m, 4.0 m (4.5 m only for pellets), articulated blade stirrer: Ø 4.0 m, 4.5 m, 5.0 m, 5.5 m

Q	Screw length (from connection point: head piece drop shaft to the fire shutter): up to 15°: ≤ 12 m; 15° – 45°: ≤ 6 m
Q2	45° : ≤ 4,39 m, 15° : ≤ 11,60 m
RI	Screw length: up to 15°: ≤12 m; 15° - 25°: ≤6 m
R2	Screw length open


## STORAGE ROOM ADJACENT TO **HEATING ROOM**

Illustration type MF2 D 100-120 kW

#### **Outline**



#### **Outline**




- Wall duct 60×60 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
  - False floor optional it is possible to install the conveyor channel in a recess in the floor. (Rear ventilator and acoustic decoupling are recommended)
- Smoke tube and chimney model according to "Technical specifications" table Energy-saving damper: installation with blowblack flap
- 20-50 kW: 84,9 cm; 60-120 kW: 92,4 cm


- Ventilation heating room  $5\,\text{cm}^2$  per kW, but at least  $\geq 400\,\text{cm}^2$
- Ceiling load / static loads must be taken into account!
  Strictly comply with local fire safety regulations and other regulations!
  Maintain the legally prescribed distances to flammable parts!

# STORAGE ROOM ADJACENT TO HEATING ROOM

Illustration with type MF2 D 100-120 kW



**Ground plan** 




- A Emergency stop switch: Boiler NOT de-energised, but combustion stopped heat dissipation continues!
- Wall duct 60×60 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- F Fire extinguisher

- Hatch: protective door boards for pressure relief
- Chimney: smoke tube and chimney model according to "Technical specifications" table, energy-saving damper: installation with blowblack flap


# STORAGE ROOM ADJACENT TO HEATING ROOM

Illustration type MF2 D 100–120 kW



#### **Ground plan**


**Outline** 




- A Emergency stop switch: Boiler NOT de-energised, but combustion stopped heat dissipation continues!
- False floor optional it is possible to install the conveyor channel in a recess in the floor (we recommend rear ventilation and acoustic decoupling)
- Wall duct 60×60 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- Fire extinguisher
- Chimney: smoke tube and chimney model according to "Technical specifications" table, energy-saving damper: installation with blowblack flap

## STORAGE ROOM ADJACENT TO **HEATING ROOM**

Illustration type MF2 D 100-120 kW



**Outline** 



**Ground plan** 


- False floor optional it is possible to install the conveyor channel in a recess in the floor (we recommend rear ventilation and acoustic decoupling)
- Wall duct 60×60 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- Hatch: protective door boards for pressure relief
- Chimney: smoke tube and chimney model according to "Technical specifications" table, energy-saving damper: installation with blowblack flap


- $\bullet$  Ventilation heating room  $5\,\text{cm}^2$  per kW, but at least  $400\,\text{cm}^2$
- Ceiling load / static loads must be taken into account!
   Strictly comply with local fire safety regulations and other regulations!
   Maintain the legally prescribed distances to flammable parts!

# STORAGE ROOM AT A DISTANCE FROM THE HEATING ROOM

Illustration type MF2 D 100-120 kW

#### **Outline**







- A Emergency stop switch: Boiler NOT de-energised, but combustion stopped heat dissipation continues!
- False floor optional it is possible to install the conveyor channel in a recess in the floor. (Rear ventilator and acoustic decoupling are recommended)
- Nall duct 50×50 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- Mall duct 60x60cm; seal after installation, channel must be acoustically decoupled
- F Fire extinguisher
- Chimney: smoke tube and chimney model according to "Technical specifications" table, energy-saving damper: installation with blowblack flap
- NI Dumping height upon request (depends on width, length and fuel)
- R Screw length ≤1,200 cm

# STORAGE ROOM ABOVE HEATING ROOM

Illustration type MF2 D 100-120 kW






- A Emergency stop switch: Boiler NOT de-energised, but combustion stopped heat dissipation continues!
- False floor optional it is possible to install the conveyor channel in a recess in the floor. (Rear ventilator and acoustic decoupling are recommended)
- Mall duct 60×60 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- F Fire extinguisher


- Hatch: protective door boards for pressure relief
- Chimney: smoke tube and chimney model according to "Technical specifications" table; energy-saving damper: installation with blowblack flan
- 2 Ceiling duct 30×30 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)

# STORAGE ROOM ADJACENT TO HEATING ROOM

Illustration with type MF2 D 100-120 kW stirrer with filling screw

#### **Outline**






- Emergency stop switch: Boiler NOT de-energised, but combustion stopped –
- heat dissipation continues!

  All Emergency stop switch or push button: at the motor
- Emergency stop switch or push button with key: at the door to the fuel storage room
- A3 Door contact end switch: on the door frame to the fuel storage room
- Emergency stop switch + ON button + OFF button: at the operator station at the filling shaft
- False floor optional it is possible to install the conveyor channel in a recess in the floor (Rear ventilator and acoustic decoupling are recommended)
- Wall duct 60 × 60 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)

- Wall duct 80×80cm; seal after installation; the channel must be acoustically decoupled (at least 2cm acoustic insulation)
- Wall duct Ø10 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- F Fire extinguisher
- H Hatch; protective door boards for pressure relief
- K Chimney: smoke tube and chimney model according to "Technical specifications" table; energy-saving damper: installation with blowblack flap
- SG Tightly bolted protective grille Mesh width 20 cm

## FILLING SCREW FOR WOOD CHIP **STORAGE ROOM**



Fuel:	Wood chips up to P16B or P45A
Displacement volume:	up to approx. 30 m³/h
Motor power:	4kW or 5.5 kW
Mains connection motor:	400 V <sub>AC'</sub> plug CEE 5/16 A
Safety class motor:	IP55


D5	Wall duct 80×80 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
EL	End bearing
ВМ	Drive motor
MI	Motor bearing
A4	Emergency stop switch + ON button + OFF button: at the operator station at the filling shaft
Al	Emergency stop switch or push button: at the motor


S1	Filling screw, part 1
S2	Filling screw, part 2
S3	Filling screw, part 3
SG	Protective grille
SL	Max. filling screw length
ZL	Intermediate bearing

- Ventilation heating room 5 cm² per kW, but at least 400 cm²
  Ceiling load / static loads must be taken into account!
  Strictly comply with local fire safety regulations and other regulations!
  Maintain the legally prescribed distances to flammable materials!

# CONVEYOR SYSTEM FOR DOUBLE HEATING SYSTEMS


Illustration with type MF2 D 100–120 kW double heating system with Y-stirrer






- Wall duct 50×50 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- Wall duct 60×60 cm; seal after installation; the channel must be acoustically decoupled (at least 2 cm acoustic insulation)
- Hatch: protective door boards for pressure relief
- Chimney: smoke tube and chimney model according to "Technical specifications" table, energy-saving damper: installation with blowblack flap
- Ventilation heating room 5 cm² per kW, but at least 400 cm²
- Ceiling load / static loads must be taken into account!
- Strictly comply with local fire safety regulations and other regulations!
- Maintain the legally prescribed distances to flammable materials!

# **INSTALLATION DIMENSIONS**





		MF2 20	⊢50 kW	MF2 60	-80 kW	MF2 115	–120 kW
[cm]		D	ZI	D	ZI	D	ZI
HI	Average height of dropping edge above cellular wheel using woodchips according to P16B	79	-	79	-	79	-
	Average height of dropping edge above cellular wheel using woodchips according to P45A	-	-	89	-	89	-
	Average height of dropping edge of the intermediate hopper		107	-	107	-	107
H2	Height KWB Multifire	159	159	167	167	167	167
Н3	Minimum room height	200	200	215	215	215	215
LI	ee space	20	20	20	20	20	20
L2	Heating system length P16B / P45A	206 / –	215 / –	222 / 229	231 / –	234 / 241	243 / –
L3	Free space	6	6	6	6	6	6
L4	Mininum room length	>232	>241	>248	>257	>260	>269
TI	Free space 40		40	40	40	40	40
	Heating system depth	123	123	134	134	134	134
T3 Free space		6	6	6	6	6	6
T4	Minimum room depth	>169	>169	>180	>180	>180	>180


**D** ... KWB Multifire Type MF2 D **ZI** ... KWB Multifire Type MF2 ZI


#### Measurements for bringing-in the boiler

KWB Multifire	Largest part of boiler as delivered	Largest part of boiler after deconstruction
Type MF2 D / ZI 20-50 kW	70 x 153	70 x 106
Type MF2 D / ZI 60-120 kW	80 x 161	80 x 125

Information regarding hydraulics requirements can be downloaded at **www.kwb.net** 

# **CONNECTING DIMENSIONS**





Legend	Connecting dimensions MF2	20-50 kW	60-80 kW	100-120 kW
		Ø 15	Ø 18	Ø 20
AR	Exhaust gas pipe	H: 176	H: 185	H: 185
AR	Extinust gus pipe	B: <b>72</b>	B: 85	B: 85
		T: 37	T: 42	Ø 18
		Ø 25, G 5/4"	Ø38, G 2"	Ø38, G 2"
VL	Forward flow	H: 157 H: 180	H: 180	
VL.	Forward now	B: 44	B: 44	B: 44
		T: 32	T: 36	T: 36
		Ø 25, G 5/4"	∅38, G 2"	∅38, G 2"
RL	Return flow	H: 157	H: 180	H: 180
KL	Retuilliow	B: 44	B: 44	B: 44
		T: 56	T: 65	T: 65
		ØR 1"	ØR 1"	ØR 1"
SG	Safety group	H: <b>157</b>	H: <b>171</b>	H: <b>171</b>
30		B: <b>72</b>	B: 93	B: 93
		T: 17	T: 19	T: 19
		ØR 1/2"	ØR 1/2"	ØR 1/2"
TA	Thermal safety valve –	H: <b>107</b>	H: 127	H: 127
IA.	inflow	B: 29	B: 31	B: 31
		T: 42	T: 47	H: 185 B: 85 T: 42 Ø 38, G 2" H: 180 B: 44 T: 36 Ø 38, G 2" H: 180 B: 44 T: 65 Ø R 1" H: 171 B: 93 T: 19 Ø R 1/2" H: 127 B: 31 T: 47 Ø R 1/2" H: 127 B: 31 T: 37 Ø R 1/2" H: 127 B: 31 T: 37
		ØR 1/2"	ØR 1/2"	ØR 1/2"
TA	Thermal safety valve –	H: 107	H: 127	H: 127
IA.	discharge	B: 29	B: 31	B: 31
		T: 32	T: 37	T: 37
		ØR 1/2"	ØR 1/2"	ØR 1/2"
KFE	Connecting height boiler	H: 22 & 23	H: 22 & 23	H: 22 & 23
NFE	filling and emptying	B: 35 & 124	B: 35 & 141	B: 35 & 153
		T: 61 & 67	T: <b>72</b> & <b>79</b>	T: 72 & 79

# **TECHNICAL SPECIFICATIONS**

MF2 D / MF2 ZI	Unit	20	30 <sup>2</sup>	40	45 <sup>2</sup>	50 <sup>2</sup>	60 <sup>2</sup>	65 <sup>2</sup>	69,5 <sup>2</sup>	80	100 <sup>2</sup>	105 <sup>2</sup>	120
						49,5					99		
Rated power	kW	20	30	40	45	50	60	65	70	80	100 101	105	120
Partial load	kW	6,0	9,0	12,0	13,5	15,0	18,0	19,5	20,9	24,0	30,0	31,5	36,0
Boiler efficiency at rated power	%	> 92	> 92	> 93	> 93	> 93	> 93	> 92	> 92	> 92	> 92	> 92	> 92
Boiler efficiency at partial load	%	> 90	> 91	> 92	> 92	> 92	> 92	> 92	> 92	> 92	> 92	> 92	> 92
Boiler class according to EN 303-5:2012	-	5	5	5	5	5	5	5	5	5	5	5	5
Water side Water content	-	155	155	135	135	135	165	165	165	165	195	195	195
Water Content	Inch	5/4	5/4	5/4	5/4	5/4	2	2	2	2	2	2	2
Water connection, forward/return flow (internal thread)	mm	31,8	31,8	31,8	31,8	31,8	50,1	50,1	50,1	50,1	50,1	50,1	50,1
	DN	32	32	32	32	32	50	50	50	50	50	50	50
	Inch	5/4	5/4	5/4	5/4	5/4	6/4	6/4	6/4	6/4	2	2	2
Water connection, forward/return flow (internal thread)	mm DN	31,8 32	31,8 32	31,8 32	31,8 32	31,8 32	38,1 40	38,1 40	38,1 40	38,1 40	50,1 50	50,1 50	50,1 50
Water connection for filling and/or emptying (internal thread)	inch mm	3/4 19,05											
Make a second traction of the second of the second through	Inch	1/2	1/2	1/2	1/2	1/2	1/2	1/2	1/2	1/2	1/2	1/2	1/2
Water connection for thermal safety valve (external thread)	mm	12,7	12,7	12,7	12,7	12,7	12,7	12,7	12,7	12,7	12,7	12,7	12,7
Thermal safety valve: pressure	bar	2–6	2–6	2–6	2–6	2–6	2–6	2–6	2–6	2–6	2–6	2–6	2–6
Thermal safety valve: required cold water temperature	°C	20	20	20	20	20	20	20	20	20	20	20	20
	mbar	36,97	85,38	153,75	200,2	242,08	56,10	67,2	77,2	100,61	158,03	172,8	228,37
Water-side resistance at 10 K	Pa	3697	8538	15375	20020	24208	5610	6720	7720	10061	15803	17280	22837
Water-side resistance at 20 K	mbar	8,51	20,24	36,97	48,4	58,68	13,53	16,3	18,7	24,49	38,68	42,3	56,10
	Pa *C	851	2024	3697	4840	5868	1353	1630	1870	2449	3868	4230	5610
Boiler-entry temperature	°C	55-70 90	55-70										
Working temperature/operating temperature  Maximum permitted temperature	°C	95	95	95	95	95	95	95	95	95	95	95	90 95
Max. operating pressure	bar	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5
Exhaust-gas side (for chimney calculation)													
Combustion chamber temperature	°C	900–1100	900–1100	900–1100	900–1100	900–1100	900–1100	900–1100	900–1100	900–1100	900–1100	900–1100	900–1100
Combustion chamber pressure	mbar Pa	-0,55 -550											
	mbar	0,05	0,05	0,05	0,05	0,05	0,05	0,05	0,05	0,05	0,05	0,05	0,05
Required draft at rated power	Pa	5	5	5	5	5	5	5	5	5	5	5	5
Required draft at partial load	mbar	0,03	0,03	0,03	0,03	0,03	0,03	0,03	0,03	0,03	0,03	0,03	0,03
	Pa -	3	3	3	3	3	3	3	3	3	3	3	3
Suction required: yes Exhaust-gas temperature at rated power	°C	140	140	140	140	140	140	140	140	140	140	140	140
Exhaust-gas temp. Partial load	°C	100	100	100	100	100	100	100	100	100	100	100	100
Exhaust-gas mass flow at rated power	kg/s	0,014	0,021	0,029	0,032	0,036	0,043	0,046	0,050	0,057	0,071	0,082	0,086
Exhaust-gas mass flow at partial load	kg/s	0,005	0,006	0,010	0,009	0,010	0,012	0,013	0,014	0,016	0,020	0,023	0,024
Exhaust-gas mass flow at rated power	kg/h	51,3	77,0	102,6	115,5	128,3	154,0	166,8	178,3	205,3	256,6	295,1	307,9
Exhaust-gas mass flow at partial load	kg/h	18,5	27,8	37,0	41,7	46,3	55,5	60,2	64,3	74,1	92,6	106,5	111,1
Exhaust-gas volume at rated power Exhaust- gas volume at partial load	Nm³/h Nm³/h	40,1 14,5	60,1 21,7	80,2 28,9	90,2 32,5	100,2 36,1	120,2 43,4	130,3 47,0	139,3 50,2	160,3 57,8	200,4 72,3	230,5 83,1	240,5 86,7
Incline of the exhaust-gas pipe	•	≥3	≥3	≥3	≥ 3	≥3	≥ 3	≥3	≥ 3	≥ 3	≥3	≥ 3	≥3
Connection height exhaust-gas pipe	mm	1735	1735	1735	1735	1735	1830	1830	1830	1830	1830	1830	1830
Exhaust-gas pipe diameter	mm	150	150	150	150	150	180	180	180	180	200	200	200
Chimney diameter (approx. values)	mm	150	150	180	180	180	180	180	200	200	220	220	220
Chimney design: Moisture-resistant  Fuel: Wood chips, EN 14961-4	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Maximum water content	-	M40											
	_						P16B						
Maximum fuel size		P16B	P16B	P16B	P16B	P16B	P45A						
Ash													
Ash container volume	l l	70 80											
Ash container filled Ash removal system	kg –	8U ✓	8U ✓	8U ✓	80 ✓	8U ✓	- 80 - ✓						
Electrical system													
		400 V <sub>AC</sub>											
Connection: CEE 5-pole	-	50 Hz											
		13 A											
Connected power MF2 D: P16B/P45A	W	1769	1769	1769	1769	1769 -	1827 2207						
Connected power MF2 ZI	W	1655	1655	1655	1655	1655	1713	1713	1713	1713	1713	1713	1713
Weights													
Water jacket	kg	300	300	340	340	340	360	360	360	360	450	450	450
Boiler body	kg	265	265	265	265	265	320	320	320	320	320	320	320
Boiler weight MF2 D (P16B/P45A)	kg	920	920	980	980	980	1100 1129	1100 1129	1100 1129	1100 1129	1200 1229	1200 1229	1200 1229
Boiler weight MF2 ZI	kg	890	890	930	930	930	1070	1070	1070	1070	1170	1170	1170
2010. 110.gittiii £ £1	кy	000	030	550	000	000	1010	1010	1010	1070	1110	1110	1110

MF2 D / MF2 ZI	Unit	20	30 <sup>2</sup>	40	45 <sup>2</sup>	50 <sup>2</sup>	60 <sup>2</sup>	65 <sup>2</sup>	69,5 <sup>2</sup>	80	100 <sup>2</sup>	105 <sup>2</sup>	120
Emissions according to test report													
Wood chips, Ref. 10 % O <sub>2</sub> dry (EN303-5)													
CO at rated power	mg/Nm³	16	12	< 7	< 7	< 7	< 7	< 7	< 7	< 7	< 7	< 7	< 7
CO at partial load	mg/Nm³	102	83	63	58	53	44	39	34	24	22	21	19
NO <sub>x</sub> at rated power	mg/Nm³	132	121	109	106	104	99	96	94	88	107	112	126
NO <sub>x</sub> at partial load	mg/Nm³	110	107	103	102	100	98	96	95	92	88	86	83
OGC at rated power	mg/Nm³	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4
OGC at partial load	mg/Nm³	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4
Dust at rated power	mg/Nm³	15	16	17	17	18	19	19	19	20	20	19	19
Dust at partial load	mg/Nm³	11	12	13	13	13	13	13	13	13	14	14	14
Wood chips, Ref. 11 % O <sub>2</sub> dry													
CO at rated power	mg/Nm³	14	11	< 7	< 7	< 7	< 7	< 7	< 7	< 7	< 7	< 7	< 7
CO at partial load	mg/Nm³	93	77	60	55	51	42	37	33	23	21	20	18
NO <sub>x</sub> at rated power	mg/Nm³	120	110	99	97	94	90	87	85	80	97	101	114
NO <sub>x</sub> at partial load	mg/Nm³	100	97	94	93	92	89	88	87	84	80	79	76
OGC at rated power	mg/Nm³	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4
OGC at partial load	mg/Nm³	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4
Dust at rated power	mg/Nm³	14	15	15	15	16	17	17	17	18	18	18	18
Dust at partial load	mg/Nm³	10	11	11	11	11	11	11	11	11	12	12	13
Wood chips, Ref. 13 % O <sub>2</sub> dry													
CO at rated power	mg/Nm³	11	8	< 5	< 5	< 5	< 5	< 5	< 5	< 5	< 5	< 5	< 5
CO at partial load	mg/Nm³	74	61	48	44	41	33	29	26	18	16	16	14
NO <sub>x</sub> at rated power	mg/Nm³	96	88	79	77	75	72	70	68	64	78	81	91
NO <sub>x</sub> at partial load	mg/Nm³	80	78	75	74	73	71	70	69	67	64	63	61
OGC at rated power	mg/Nm³	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3
OGC at partial load	mg/Nm³	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3	< 3
Dust at rated power	mg/Nm³	11	12	12	12	13	13	13	13	14	14	14	14
Dust at partial load	mg/Nm³	8	9	9	9	9	9	9	9	9	10	10	10
Wood chips, In accordance with § 15a-BVG Austria													
CO at rated power	mg/MJ	8	6	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4	< 4
CO at partial load	mg/MJ	50	41	32	30	27	22	20	17	12	11	10	9
NO <sub>x</sub> at rated power	mg/MJ	66	60	54	53	51	49	47	46	43	53	55	62
NO <sub>x</sub> at partial load	mg/MJ	54	53	51	50	50	49	48	47	46	44	43	41
OGC at rated power	mg/MJ	< 2	< 2	< 2	< 2	< 2	< 2	< 2	< 2	< 2	< 2	< 2	< 2
OGC at partial load	mg/MJ	< 3	< 3	< 2	< 2	< 2	< 2	< 2	< 2	< 2	< 2	< 2	< 2
Dust at rated power	mg/MJ	7	8	8	8	9	9	9	9	10	10	10	10
Dust at partial load	mg/MJ	5	6	6	6	6	6	6	6	6	7	7	7

#### 28.01.2014

 $mg/Nm^3 \dots milligram \ per \ standard \ cubic \ meter \ (Nm^3 - standard \ cubic \ meter \ under \ 1013 \ hectopascal \ at \ 0 \ ^{\circ}C)$ 

<sup># ...</sup> The test reports will be available shortly. Detailed values and technical data on fuels such as pellets or agricultural fuels can be downloaded under www.kwb.net

<sup>1 ...</sup> Drawing inspection

<sup>2 ...</sup> Typification variants

## REQUIRED STRUCTURAL CONDITIONS

#### Note

Always observe the local statutory submission, construction and execution regulations that apply to you as a KWB system user! You can obtain these regulations, from the architect or competent authorities or similar authorities. Adherence to and verification of the local statutory regulations is a precondition for our guarantee, warranties and for your insurance coverage. KWB does not accept any liability, nor does it offer any warranties for any type of building measures. Proper execution of building measures is the sole responsibility of the system owner. As a biomass heating system user, you may be entitled to receive specific regional subsidies. Inquire promptly about time limits and procedures for handling subsidy applications. Comply with the dimension specifications in the installation examples and technical specifications. Without laying claim to an exhaustive treatment of the issue at hand and without suspension of any conditions imposed by the authorities, based on the Austrian Directive TRVB H 118 and ÖKL technical bulletins No. 56 and No. 66, we recommend the configuration described below.

#### **Heating room**

Concrete flooring, plain or tiled; height-adjustable system feet can be used to compensate minor irregularities. All materials for floors, walls and ceilings must be fire resistant in REI90\*; the heating room door (see boiler dimensions table for moving the boiler into the room) as it is a fire door (Ela-30-C\*) must open in escape direction and close automatically, the connection door to the fuel storage room must be an automatically closing fire door (El<sub>2</sub>-30-C\*). Non-opening E30\* Heating room window; non-closing intake air opening 5 cm² per kW rated power of heating system, but no less than 400 cm<sup>2</sup>. If the boiler output is > 60 kW, it is necessary to integrate one ventilation opening near the floor and another ventilation opening near the ceiling; the supply air ducting must be routed directly into the opening; if it crosses other rooms, the air duct must feature an 190\* envelope; a protective grille with a mesh width of < 5 mm must be fitted on the outside of ventilation openings. Permanently installed lighting and electrical supply to the heating system; light and labelled emergency stop switch of the heating system, in an easily accessible location outside the heating room in the vicinity of the heating room door. A portable fire extinguisher (6 kg filling weight, EN3 standard) must be installed outside the heating room near the heating room door. The heating room as well as water lines and district heating pipes must be frost-resistant. There must be no storage of inflammable materials in the heating room outside the boiler system, storage container or hopper; no

direct connection to rooms where inflammable gases or liquids (garage) are stored. You must comply with the local installation regulations.

#### Fuel storage room

The structural requirements for the heating room also apply to the fuel storage room. The stirrer is installed in the middle of the storage room and is fastened to the concrete floor with anchor bolts. A rear-ventilated false floor/inclined floor should be installed at the same level as the top edge of the fuel extractor. The wall duct (width 60 cm, height 60 cm) for the screw channel between the storage room and heating room should be partitioned such that it is fireproof (e.g. with mineral wool). If a pumping car is used to fill the fuel storage room with wood chips or pellets, it is necessary to mount hose couplings and pipelines (to be earthed) which are available from KWB. If this filling method is chosen, dust proof sealing of the fuel storage room is required. The escaping air is removed through a second earthed pipeline and hose coupling, or it is blown off into the open air after having passed through a filtering section. Suction removal or filtration of the transport air is the responsibility of the fuel supplier. The walls, windows and doors must withstand the overpressure created during the filling process. In the event of bulk fuel storage, no electrical installations are permissible in the fuel storage room since they pose an ignition hazard. KWB biomass heating systems are supplied with all the necessary fire-protection equipment included. Depending on the local installation situation, type of fuel and amount of storage, a manually triggered fire extinguisher and/or the built-in fire extinguisher may have to be connected to a pressurised water line. The fire extinguisher with manual release, featuring a frost-proof connection (from the heating room), is to be fitted at least 34" or as DN20 directly above the conduit of the fuel-extractor channel leading into the fuel storage room in the form of empty piping. The shut-off device which is to be installed in the heating room, must be marked with the following sign "Fire extinguisher - fuel-storage room". A fire extinguisher with manual release must be installed in a storage systems containing 50 to 200 m<sup>3</sup> of wood chips for systems up to and including 400 kW. If such a fuel-storage room is built next to fire-resistant structural components without openings, a REI90\* enclosure/sheathing is not necessary. In the case of wood chip storage rooms in utility outbuildings with a fire wall facing the living quarters, a REI90\* design/sheathing of the fuel-storage room is not necessary if the fire section is smaller than 500 m<sup>2</sup>. Fuel must be stored separately from other goods (e.g. by means of wooden planking). >> A manual-release extinguisher and an integrated extinguishing system must be installed. In the case of storing up to (and including) 200 m<sup>3</sup> of other wood materials (with dust) in systems up to and including 400 kW, an integrated extinguisher must be installed in addition to a manualrelease extinguisher. For systems greater than 400kW or stored quantities greater than 200 m³, both (a manualrelease extinguisher and an integrated extinguisher) are necessary (see TRVB H 118). Additional statutory safety and acceptance conditions apply to storage rooms and silos that are continuously suction-fed with shavings or sanding dust. If you have any questions, please contact your KWB factory representative. Above-ground fuel stores must be accessible to the outside by means of a door measuring at least 1.80 m<sup>2</sup> across, which should be planked to prevent the fuel from trickling outside should the door be opened by mistake. The planking should be removable from the outside. An inspection opening (REI90\*) must be installed above the fuel extractor channel. Please refer to the installation examples.

#### Ventilation in the pellet storage room

The storage rooms and storage containers must be ventilated according to ÖNORM M7137 to prevent an increased CO concentration. The vents in storage rooms with a capacity up to 30 tons must lead to the outside. This is ensured by ventilated filling nozzles (available from KWB) that lead out into the open. Filling nozzles that do not lead to the open air must not be ventilated! In this case, ventilation must be ensured through a separate ventilation opening in the storage room (ventilation cross section  $\geq 200 \, \text{cm}^2$ ). This ventilation opening must be configured so that no dust can escape during the air-injection process and that the ventilation is operational after the filling of the storage (and not covered by pellets, or other debris). Care must be taken to ensure that no rainwater can penetrate into the pellet storage via the ventilation openings. To remove the risk of a carbon monoxide build-up in storage rooms with a capacity of more than 30 tons, one of the following two options must be selected:

- A work organisation system that is combined with a natural or mechanical ventilation based on carbon monoxide sensors or
- A state-of-the-art forced ventilation system

#### Chimneu

Due to the high boiler efficiency, the chimney design should be resistant to moisture. A moisture-resistant chimney design means that there will be no moisture penetration or damage to the brickwork, although the temperature level in the exhaust gas path is permanently below the exhaust gas dew point (see DIN 18160). The approximate values for the chimney diameter are stated in the specifications. These apply to the respective size of the system based on the average structural conditions, meaning: effective

chimney height 8–10 m, 1.5 m smoke tube length, 2 segment bends at 90° each, 1 contraction, 1 T connection at 90°. You must comply with the specifications in the cross-section diagrams provided by the chimney manufacturer. If conditions differ or are less favourable in terms of space, it is necessary to carry out a chimney calculation according to DIN 13384. KWB provides an electronic data entry sheet for this purpose. Upon request, KWB will provide the chimney calculation based on the information provided on the form. This is a chargeable service. The local expert for these issues is your responsible chimney sweep. It is advisable to involve your chimney sweep during the planning phase as he is the one who will have to issue the acceptance certificate for the exhaust gas system.

## Installing the heating system Placement of the heating system

To be performed exclusively by qualified, trained personnel of KWB or KWB associates. Licensed heating and electrical installers must connect the heating system to the chimney, water and electrical system; this must be verified for numerous reasons, e.g. in order to be eligible for subsidies.

#### Smoke tube connection on the chimney

If not already required by local regulations, we recommend that a draft limiter and a blowback flap be built into the smoke tube, or chimney side wall, and arranged in such a manner as to exclude any danger to persons. Keep the smoke tube as short as possible. The smoke tube must be insulated and connected, and should at least ascend slightly towards the chimney, preferably with an inclination of less than 45°. The smoke tube should be thermally insulated and feature suitable, easily accessible cleaning openings. The chimney connection should be 20 mm larger than the smoke tube diameter. In this way, it is possible to integrate a suitable acoustic transmission decoupler between the smoke tube and the chimney. The KWB system is by default equipped with an induced draught fan.

#### Water connection

When using wood chips, the return flow inlet temperature into the boiler must be at least 55 °C, when using pellets at least 50 °C, otherwise there is an increased risk of corrosion, which also has the effect of voiding the guarantee and warranty. To increase the temperature of the return flow, the boiler control unit can activate a mixing controller. For systems to 60 kW the return flow boost

can also be executed via a thermal control valve. Suitable fittings to increase the return flow temperature are available from KWB. With the exception of cases where the return flow temperature is maintained by a mixing pump of KWB, the heating

system must feature a pressureless distribution system (switch, distributor, load-balancing tank, buffer, thermal regulator, etc.) and a safety group that complies with the

relevant regulations (e. g. according to ÖNORM EN 12828 or EN303). KWB recommends the installation of an intelligent buffer tank storage when installing a biomass heating system, which can be considered the energy centre of the heating system. As a result, the owner saves on heating costs due to lower fuel consumption, increases the annual efficiency coefficient as well as the profitability of the heating system and ensures perfect system solutions and lower emissions. The reason for this is that the heating system is focused on the coldest time of the year, this type of performance, however, is rarely needed and especially in transition periods, barely utilised. This leads to frequent burner starts, which has a negative effect on fuel consumption and the entire service life of the heating system. The effect is comparable to the stop-and-go traffic on the road. As a rule, a pellet heating system, however, does not need a buffer storage tank, we recommend it, for the aforementioned reasons. In exceptional cases, a buffer or load balancing storage tank is required:

- Oversizing: When the rated boiler output exceeds the entire building heat requirements by 50%, you will need a buffer storage tank (this is often the case when buildings are enlarged or in the case of low energy houses. In the event of such dimensioning, a large portion of the operating time the boiler will run under the boiler's smallest modulation degree.
   When using the buffer storage tank, the boiler can be operated in the preferred load range.
- Very small heating loads in summer/during transition periods, e.g. when only the bathroom is heated in summer/the transition period, the operation of only one or two heating units during transition periods, domestic hot water preparation in summer in a heating network without block charge, ...
- If parts of the heat dissipation system are frequently switched off or in the event of a high passive solar contribution
- In case of large demand for warm water, e.g. hotels, showers in sports facilities, large multi-family houses
- To cover peak periods in the morning, e.g. in production facilities or schools
- After integration of a solar power heating system or a logwood boiler
- Multi-boiler systems (boiler master-and-slave circuits)

Your installer can advise you specifically with regard to the water connection. Components of acoustically-insulated water connections must be impermeable to oxygen; otherwise there is an increased risk of corrosion, which also has the effect of voiding the guarantee and warranty. If plastic pipes for floor heating systems or district heating pipes are connected, it is necessary to integrate a limiting thermostat for the boiler circuit pump to provide additional protection against excessive temperatures. With respect to the condition of the boiler water, VDI 2035 and ÖNORM H 5195 T1 and T2 must be unconditionally complied with; otherwise there is a risk of corrosion, which may void the guarantee and warranty.

## Electrical connections of the KWB Multifire system

The entire system-internal wiring is executed in the factory or is executed plug-ready by installation personnel. On site, only a licensed electrical installation company should execute the mains connection and the boiler-external cabling, and in the case of a network, the bus cabling of the heating circuit expansion modules and for the room control units.

#### Required connections to be provided by customer:

- CEE socket supply 5-pole (L1/L2/L3/N/PE), with fault current protection switch and overvoltage arrester for the house distribution board (recommended as lightning protection), 400 V<sub>ac</sub> line protection switch 13 A, type C
- $\bullet$  Danger switch "emergency stop" (230  $V_{\text{AC}}$  cable cross section at least 1.5  $\text{mm}^2)$
- $\bullet$  If using KWB Comfort SMS: outlet 230  $V_{_{\Delta C}}$
- $\bullet$  If using fuel extractor modules: per module 1 CEE socket 5-pole (L1/L2/L3/N/PE), 400  $\rm V_{\rm \tiny AC}$

#### Outputs:

Floating contacts with max. 2 A switched current, 230  $V_{\scriptscriptstyle AC}$ 

• Fault warning output.

Combined fault warning contact (e.g. for remote warning through telephone dialling).

- Fault 1: NC contact to indicate faults.
- Fault 2: NO contact to indicate faults.
- Power (the following options are also possible as alternatives):

NO, configurable for.

- Burner operation display (modulation between partial load and nominal load).
- Boiler master-and-slave circuit to request a second boiler.
- Fuel extractor for common stirrer drive.
- Smoke extractor.
  - NO contact for activating an external smoke extractor.
  - The boiler is released by the controller of the external. smoke extractor via external 1 (floating contact).

#### Inputs:

 $24\,V_{nc}$  supply to connect floating contacts.

• External 1: To switch on the boiler (e. g. when using a smoke extractor).

If this input is not used, it must be short-circuited.

- External 2: Multifunction input.
- Heating to desired 2: To request the boiler with the second boiler temperature desired temperature or as a request contact for external third-party controls (request duration should be at least 30 minutes).
- For holiday remote control (does not work with external boiler request).
- Emergency stop switch:

Connection of the emergency stop s witch (in accordance with applicable regulation TRVB H 118)

<sup>\*</sup> in accordance with ÖNORM EN 13501

#### **KWB Power Converter**


A KWB Power Converter is necessary to be able to operate KWB Multifire heating systems in 230 V-networks. The KWB Power Converter is only suitable for the KWB Multifire with max. I conveyor system motor. The KWB Power Converter is pre-wired internally, but must be connected to the boiler and the mains during installation.


#### Consisting of:


- Switch box for wall mounting
- 3 frequency converters (main drive motor, heating exchange motor and conveyor system motor)
- Activation electronics

## **Bus system – conditions**

- Bus cable: CAT.5e, S/FTP; 4 × 2 × AWG 24, maximum length 850 m, for underground installation: CAT.5e, 4 × 2 × 0.5 mm<sup>2</sup>.
- Laid out in a separate conduit (not together with  $230/400\,\mathrm{V}_{\mathrm{ac}}$ ).
- Network stations in one line (no branches, no ring).
- If the boiler control unit in the room is used, it is necessary to install an empty base with bus connector CAT.5e (not possible in combination with the KWB Comfort SMS).
- Max. 2 digital remote control units after a heating circuit expansion module or heating-system master board are supplied with voltage. Each heating circuit module must be powered with 230 V and 50 Hz mains voltage for the heating circuit module itself and for any connected DRCUs, pumps and mixer servomotors.
- For each heating circuit, an analogue remote control unit (no bus station) can be used independent of the bus stations. Wiring is the same as for a room sensor.









## **GUARANTEES AND WARRANTIES**

FROM WARRANTY TO FULL GUARANTEE

## **Our standards**





Guarantee for Heat exchanger



Spare part delivery guarantee

## Our supplemental packages



#### Maintenance agreement

- √ 3-year guarantee
- Cost savings as compared to individual maintenance
- √ We will remind you annually



#### **Guarantee Pass**

- ✓ 6-year guarantee
- ✓ On all spare/wearing parts
- Service during replacement
  of spare/wearing parts free of
  charge as part of maintenance



#### **Full maintenance**

- √ 10-year guarantee
- Calculable fixed costs
- √ The all inclusive package

## KWB THE BIOMASS HEATING SYSTEM

#### **KWB Austria**

#### KWB - Kraft und Wärme aus Biomasse GmbH

Industriestraße 235, 8321 St. Margarethen/Raab Tel.: +43 3115 6116-0, Fax: +43 3115 6116-4 office@kwb.at, www.kwb.at

#### **KWB Germany**

## KWB Deutschland – Kraft und Wärme aus Biomasse GmbH www.kwbheizung.de

#### **Branch office, South**

Gewerbepark Ost 41, 86690 Mertingen Tel.: +49 9078-9682-0, Fax: +49 9078-9682-79 99 office-sued@kwbheizung.de

#### **Branch office, Southwest**

Mercedesstraße 8, 72108 Rottenburg a.N. Tel.: +49 7457-6999-0, Fax: +49 7457-6999-5999 office-suedwest@kwbheizung.de

#### **Branch office, Central**

Friedenbachstraße 9, 35781 Weilburg Tel.: +49 6471-91262-0, Fax: +49 6471-91262-3999 office-mitte@kwbheizung.de

#### **Branch office, West**

Hansestraße 41, 48165 Münster Tel.: +49 2501-44039-00, Fax: +49 2501-44039-4999 office-west@kwbheizung.de

#### **KWB France**

#### KWB France S.A.R.L.

www.kwb-france.fr

#### KWB France S.A.R.L.,

68000 COLMAR, 13 rue Curie Tel.: +33 3 89 21 69 65, Fax: +33 3 89 21 69 83 contact@kwb-france.fr

#### **Branch office, Rhône-Alpes**

69800 ST PRIEST, 11 Rue Aimé Cotton Tel.: +33 4 78 67 04 54, Fax: +33 4 72 90 11 62 contact@kwb-france.fr

#### Branch office, Bretagne

35530 NOYAL SUR VILAINE, Avenue du Général de Gaulle Tel.: +33 6 31 52 81 24, contact@kwb-france.fr

#### KWB Italy

#### KWB Italia GmbH

Via T.A Edison 15, 39100 Bozen (BZ)
Tel.: +39 471 05 33 33, Fax: +39 471 05 33 34
info@kwb.it, www.kwb.it

#### **KWB Slovenia**

#### KWB, moč in toplota iz biomase d.o.o.

Vrečerjeva 14, 3310 Žalec Tel.: +386 3 839 30 80, Fax: +386 3 839 30 84 info@kwb.si, www.kwb.si

#### **Additional national representation**

#### Switzerland, www.kwb-swiss.ch

#### Jenni Energietechnik AG

Lochbachstraße 22, 3414 Oberburg bei Burgdorf Tel.: +41 34 420 30 00, Fax: +41 34 420 30 01 info@jenni.ch, www.jenni.ch

#### **Energie Service Sàrl Jurg Anken**

1464 Chêne-Pâquier VD, Tel.: +41 24 430 16 16 Fax: +41 24 430 19 43 info@energie-service.ch, www.energie-service.ch

#### Netherlands, www.kwb-biomassaverwarming.nl

#### Atechpro B.V.

Mercuriusweg 11, 3771NC Barneveld Tel.: +31800-6655555 info@atechpro.nl, www.atechpro.nl

#### Belgium, www.kwb-belgium.be

#### Ökotech BeLux GmbH

Zum Hütel 19, 4770 Halenfeld Tel.: +32 80 571 98-7, Fax: +32 80 571 98-8 info@oekotech.be, www.oekotech.be

#### Spain, www.kwb.es

#### HC Ingeniería y Biomasa, S.L.

Av Comandante Franco, 6, 28016 Madrid Tel.: +34 91 548 30 25 info@hcib.es, www.hcib.es

#### Chile, www.kwb.cl

#### Energiadelsur

Carretera Gral. San Martín 9340 - P, Quilicura, Santiago Tel.: +56 2 376 5071, Fax: +56 2 443 5421, Mobil: +56 9 9822 5780 michael.schmidt@energiadelsur.com, www.energiadelsur.com

#### Ireland, www.kwb.ie

#### Original Heating Ltd.

67 Culmore Road, BT48 8JE L'Derry, Northern Ireland Tel.: +44 28 71353108, Fax: +44 28 71350970 info@originalheating.com, www.originalheating.com

#### Technical Energy Solutions Ltd.

Four Piers, Cregg, Carrick on Suir, County Tipperary Tel.: +353 51 83 32 82, Fax: +353 51 64 11 22 info@tes.ie, www.tes.ie

#### Scotland, www.kwb-heating.co.uk

#### Original Heating Ltd.

Banchory Business Centre, Burn O Bennie Road AB31 5ZU Banchory, Aberdeenshire Tel.: +44 1330 82 65 04, Fax: +44 1330 82 06 70 info@originalheating.com, www.originalheating.com

England and Wales, www.kwb-heating.co.uk

#### TP Multiifire2 2014 EN . Index 0

As of: January 2014, Subject to changes and to typographical and printing errors.

#### Company details:

KWB - Kraft und Wärme aus Biomasse GmbH Industriestraße 235, A-8321 St. Margarethen/Raab

Tel.: +43 3115 6116-0 Fax: +43 3115 6116-4 Email: office@kwb.at Web: www.kwb.at

© Photos: KWB, Toni Muhr www.tonimuhr.at, Karl Schrotter, 1000ideen.at/Kasca

